

OWNER'S MANUAL



QM CONTROLLER



QA CONTROLLER

IMPORTANT - INSTALLER MUST COMPLETE FOR WARRANTY PURPOSES

Model:	Serial Number:
Installation Date:	Installed by:
Dealer:	Invoice No:

CAUTION

- This appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given instruction or are supervised.
- Children being supervised are not to play with this appliance.
- This appliance is to be permanently connected to the water mains and not to be connected by a hose-set.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.

WARNING

This evaporative cooler is not suitable to be installed in a BAL-12.5 area.

Maximizing your Coolbreeze Evaporative Air Conditioner	4
Quick Start Guide	5
QM Controller	6
QA Auto Controller	8
General Information— - All Controllers	11
Maintenance	11
Troubleshooting Guide	13
Coolbreeze Product Warranty Terms & Conditions	14/16

MAXIMISING YOUR COOLBREEZE EVAPORATIVE AIR CONDITIONER

CoolBreeze evaporative air-conditioning provides a continuous supply of cool, fresh, filtered air into your home to push out the warm, stale air.

To maximise the cooling efficiency it is important to allow sufficient window or door openings to disperse the warm, stale air.

Ceiling outlets should be positioned across the room from the window to allow the cool air to pass through the room and exit through the window.


It is possible to direct the airflow by closing the windows in an unused room and the air will flow through the opened doorway into other rooms.

Insufficient openings will restrict the airflow; it may lead to 'dampness' on floors and furniture. See below for ventilation openings required.

If you prefer not to operate your system with windows or doors open, there is the optional Security Air Relief Vent available from your CoolBreeze dealer.


This allows the escaping air to vent into the roof space rather than through the windows, which has the added benefit of providing additional insulation as it cools the air inside the roof cavity.


NATURAL DISPLACEMENT COOLING



Model	95	100	125	160	195	230	240	255	500
Opening m²	1.5	1.5	2.0	3.0	3.5	4.0	4.0	4.5	8.5

QUICK START GUIDE: ALL CONTROLLERS

- Press 'Cool'
The unit will start it's pre-start wash cycle, once the filter media is clean and wet, the fan will start up. This will take about 5 minutes.
- To bypass the pre-start wash, press 'Fan', then 'Cool'.
- Adjust fan speed as follows: Use the ▲ and ▼ buttons.
- Turn the unit off by pressing the 'Off'  button



QM CONTROLLER INSTRUCTIONS

MAIN CONTROLS

OFF 

Switches the unit off.

When the air conditioning system is switched off, the water tank is emptied and a fresh tank of water is taken in. The fresh water is used to perform a 15 minute FLUSH cycle. Fresh water rinses and cleans the pads of any impurities or minerals left from the evaporative cooling process. To by-pass the FLUSH Mode, press FAN then OFF.

FAN 

In FAN mode, the water pump is not activated and the unit will deliver ambient temperature air from outside throughout the property. Airflow is adjusted using the UP and DOWN buttons. The FAN Mode is useful when the outside ambient temperature is cool and no direct cooling from the air conditioner is required.

EXHAUST 

The EXHAUST function allows the hot air which has built up to be expelled before the cooling process starts, this can reduce the time needed to cool the property. Exhaust mode is useful for eliminating heat or odours from the property without the in-rush of air experienced with the COOL and FAN modes. It is particularly useful in winter when a cold draft of air is not desirable. A delay occurs when switching to EXHAUST Mode. This is to protect the motor and allow it time to stop, before the rotation is reversed.

COOL 

In COOL mode both the fan and water pump operate to provide cool airflow throughout the property. Air Flow can be adjusted from 1% to 100% using the UP and DOWN buttons

If the unit is operating in COOL or FAN mode when switched to EXHAUST there will be a 30 second delay to allow the motor to stop prior to reversing direction.

The system has been pre-set to provide a 5 minute pre-wash cycle before the fan starts. Water is circulated over the pads to wash off any dust. To bypass this wash cycle, press FAN and then COOL. After each 5 hours of operation a periodic drain cycle empties the tank of water. This 5 hour cycle may be altered if required. See "Water Management System Settings".

When the air conditioning system is switched off, the water tank is emptied and a fresh tank of water is taken in. This fresh water is used to perform a 15 minute FLUSH cycle. Fresh water rinses and cleans the pads of any impurities or minerals left from the evaporative cooling process. To by-pass this FLUSH cycle, press FAN then OFF.

WATER MANAGER SYSTEM SETTINGS

The water manager System has been factory set at 5 hours
The DRAIN, WASH and FLUSH cycle can be adjusted using the DIP switches on the keypad circuit board.(Service Technician only to adjust)

They function as follows:

DRAIN CYCLE INTERVAL:

5 hour cycle interval—DIP switch 1 to off position—Factory setting
2.5 Hour drain cycle interval—DIP switch 1 to ON position

PRE-START FLUSH : (USE IN DUSTY ENVIRONMENTS)

To drain the water after the initial pre-start wash
Dip switch 2 to OFF position

No drain after initial pre-start wash
DIP switch 2 to ON position (Factory setting)

END OF DAY WASH & FLASH:


To wash unit and drain when unit is switched off
DIP switch 3 to ON position (Factory setting)

No wash and drain when unit is switched off
Dip switch 3 to OFF position

DIP switch 4 must remain on the OFF position


It is advisable to have regular drain cycles to maintain water purity and cooling efficiency





FACTORY SETTING OF DIP SWITCHES







QA CONTROLLER INSTRUCTIONS

MAIN CONTROLS



Function	Screen View	Description
COOL		In COOL mode, both the fan and water pump operate to provide cool airflow throughout the property. Airflow can be adjusted from 1% to 100% using the UP and DOWN buttons. When COOL is selected the unit enters a pre-wash cycle. This 5 minute cycle washes dust and pollen off the filter media. Bypass the wash cycle by pressing FAN then COOL . Display shows Cool function at 50% fan speed.
AUTO COOL		The unit is set to run automatically to a pre-set temperature. See page 9 for details of setting this mode.
TIMER		The TIMER function switches the system on or off. Pushing the TIMER button adds 30 minutes to a maximum of 99 hours. If the unit is OFF when the TIMER is selected, the unit will automatically start in COOL mode when the timer counts down to zero. If the unit is operating in either COOL, FAN or EXHAUST mode the unit will switch off when the timer reaches zero.
FAN		In FAN mode, the water pump is not activated and the unit will deliver ambient temperature air from outside throughout the property. Airflow is adjusted using the Up and DOWN buttons. Fan operating at 50% fan speed.

EXHAUST		The EXHAUST function allows the hot air which has built up to be expelled before the cooling process starts, this can reduce the time needed to cool the property. If the unit is operating in COOL or FAN mode when switched to EXHAUST, there will be a 30 second delay to allow the motor to stop prior to reversing direction. Exhaust function operating a 50% fan speed.
OFF - Stand-by		The display panel shows the room temperature when the unit is OFF.
OFF - Safety		In the Safety - Bushfire mode the pump is on and there is no fan function. For setting details see page 10.
OFF - Housekeeping Mode		When the air conditioning system is switched off, the water tank is emptied and a fresh tank of water is taken in. This fresh water is used to perform a 15 minute FLUSH cycle. Fresh water rinses and cleans the pads of any impurities or minerals left from the evaporative cooling process. To by-pass this FLUSH Mode, press FAN then OFF. The display shows ambient temperature and housekeeping mode.

AUTO

Press the AUTO key ("A" is shown in the digit one on the display panel) and then select the desired mode COOL, FAN or EXHAUST

The "set" temperature is displayed for 5 seconds, use the UP and Down buttons to select the desired set temperature. After 5 seconds the display will show the room temperature.

The fan speed will automatically adjust to maintain the set temperature.

- As the room temperature approaches the set temperature, the fan speed will automatically slow down to it minimum speed.
- The fan remains operating at minimum speed unless the room temperature decreases to 3deg below the set temperature.
- If the room temperature reaches 3deg below the set temperature, the fan switched off and the unit is in stand-by mode.
- The fan will restart if the room temperature increases to 1 deg below the set temperature.
- After one hour in stand-by mode the unit will turn off.

A temperature that is set at an unrealistically low level will not be achieved, due to the imitations of evaporative air conditioning. A low temperature setting causes the system to operate at maximum fan speed continuously .

If either "AC", "AF" or "AE" are displayed and the fan is not operating, the system is in stand-by mode and the fan will start when the ambient temperature reaches the "set" temperature.

If only "A" is displayed the system is in AUTO mode but COOL ,FAN or EXHAUST have not been selected

The timer can operate in AUTO mode. The system switches on only if the temperature rises above the set temperature and once the timer period has elapsed.

SAFETY (BUSHFIRE) MODE

The SAFETY mode allows the water pump to continue to operate to keep the filter media wet while the fan is switched off to prevent smoke being drawn into the property.

To operate this mode do as follows

- If the unit is OFF press the “COOL” button twice. The letter “P” (Flashing) will be displayed.
- If the unit is operating in COOL mode, press the COOL button again to enter SAFETY mode.
- To turn off SAFETY mode, press the COOL button again. The unit reverts to COOL mode and the “P” on the keypad display will be replaced with a “C” .

WATER MANAGER PERIODIC DRAIN TIME

The unique Coolbreeze Water management system has been developed to ensure only fresh filtered cool air enters the property while saving water and reducing maintenance requirements. The system has a default five hour drain cycle. This five hour drain cycle is adequate for most water supplies.

To change the drain cycle do as follows

- Press OFF
- Press and hold AUTO button
- Press TIMER unit required time is reached
- Release AUTO
- Press OFF
- Press AUTO (“A” on the left display will now disappear) The periodic drain cycle has now been altered to the displayed time

It is advisable to have regular drain cycles to maintain water purity and cooling efficiency.

CALIBRATING THE TEMPERATURE

(Recommended for service technicians only)

When unit is off, the ambient room temperature is displayed. If this temperature is not accurate it can be re-set:

Using a calibrated thermometer, compare the displayed temperature against the thermometer.

Use a small screwdriver to adjust the temperature sensor which is located on the lower right side of the control panel . Place the screwdriver in the slot of the temperature sensor and turn several times (clockwise to increase the reading), there is a time lag between the turning of the pot and the keypad display changing so wait for the temperature reading on the keypad to change. This process may need to be repeated several times before the desired temperature is attained

Do not obstruct the ventilation slots in the keypad base as this may cause an incorrect temperature reading.

Temperature sensor pot



GENERAL INFORMATION: APPLICABLE TO ALL CONTROLLERS

- If the unit appears to surge at times, check that strong wind drafts are not the cause. A strong gust of wind may cause the fan to race momentarily as it is wind assisted.
- At times of high humidity, cooling performance is diminished. Ensure adequate windows are open or operate in fan only mode.
- Cooling ability of a system is not only related to the efficiency of the unit design but also to the duct design and professional installation. Insulated ceilings will lower internal temperatures significantly over non insulated ceilings.
- During operation in cool mode, water discharges from the overflow pipe. This water has been re-circulated through the pads many times. The evaporation process results in a build-up of minerals and solids in the water. This water can be channelled onto the garden but maybe harmful to some plants. Test the water on plants in small amounts before fully discharging into garden. This water is not suitable for animal or human consumption.
- Never operate the system if the room vents have been closed off. This may cause overheating and damage the motor.
- At the time of initial start up an odour may be detected. This odour is characteristic of filter media pads. It is neither harmful nor particularly unpleasant and will dissipate within 2-3 days. The fan motor may also have an "electrical" type smell for a short period as it heats up initially, and residual varnish is "burnt off" the motors surface.
- When cool mode commences the tank is filled with water, this takes approximately 90 seconds, during which time the pump remains switched off. When the pumps starts, water is pumped up into the filter media pads which quickly lowers the water level. Depending on the water pressure supplying the unit, for a short period of up to one minute the water being pumped up into the filter pads may exceed the amount of fresh water flowing into the base. The pump may make an intermittent "sucking" noise until the water level is balanced. This is not harmful to the pump.
- The filter media pads are the heat exchange mechanism which enables the cooling process. They need to be maintained and checked periodically. The life of the pads is governed by the quality of the water supplied to the unit.
- Should the keypad be illuminated but there is no airflow, switch off the unit and call for service agent.

GENERAL INFORMATION & MAINTENANCE

PRE SEASON MAINTENANCE


We recommend an annual service, to keep your system in top operating condition.

The service centre telephone number together with the unit size and serial number are recorded on the front of this guide. Electrical components to be maintained by qualified service people.

1. Isolate power at property's main supply board. Disconnect units power plug from the mains supply. If cable is damaged have it replaced by qualified person.
2. Remove the lid.
3. If necessary, clean the sump reservoir.
4. Turn on the power. Operate the system in cool mode, check that the drain valve closes and the tank fills.

5. Adjust the water level if necessary. Ideally this level should be 10mm below the overflow.
6. Check that the water is being evenly distributed over the pads and that there are no obstructions in the water distributor located above the pads.
7. It is recommended that the hoses and washers on the drain valve are replaced bi-annually.
8. Replace the lid and secure it by firmly tightening the lid bolts. Do not over tighten.

SHUT—OFF VALVE



END OF SEASON MAINTENANCE

At the end of each season, carry out the following steps:

1. Isolate the power to the air conditioner which will be located in the meter box. An internal isolator is located on the electrical box inside the unit.
2. Turn off the water supply to the unit.
3. Remove the lid and pads. Carry the pads to the ground and gently hose down both sides of the pads to remove any dust or pollen.
4. Gently but thoroughly clean the sump reservoir of the unit. A mild detergent may be used, but no solvent type product which may react with the polymer.
5. Replace the lid and ensure that it is securely fastened.

IMPORTANT INFORMATION ON MAINTENANCE NEEDS

When units are installed in certain environments for example, in bakeries, textile factories, paint shops or similar places, servicing will need to be done more frequently. When pads are clogged with lint or flour or other airborne contaminants the airflow through the pads is restricted. This will cause the motor to over-heat which could lead to failure of the motor fan assembly.

TROUBLESHOOTING GUIDE

Fault	Action
No display on Control Panel	Check circuit breaker or fuse in meter-box If circuit breaker and fuses are ON, call for service
Fan operating but blowing warm air	Check that Control Panel is set to Cool or Auto Cool Turn unit off and see if water runs from drain pipe (wait 5- 10 minutes to drain) NO - Check the water supply tap is turned on YES – call for service
Water runs continuously from unit while operating	Turn unit on and off once per hour – allowing 20 minutes between restarting. Repeat this 2 – 3 times to flush debris from unit. If water continues to run - call for service
Water runs continuously from unit when unit is turned off	Turn off water isolation tap – call for service
No airflow	Check if Control Panel display is lit: No - check circuit breaker in meter-box Yes – call for service QA controller only: Control Panel may be set in Auto mode (Display shows AC, AF or AE) Control Panel may be set in TIMER mode (Display shows numbers counting down each minute) To reset Control Panel modes, switch off circuit breaker for 10 seconds and turn on again.
Keypad shows unit is operating but there is no airflow	If the motor is fitted with a manual thermistor the mains power must be reset to the unit by turning the circuit breaker off . The motor will need to be below 80 degrees prior to resetting. Wait for 1 hour prior to resetting. If fault re-occurs call for Service.
Moisture on floors and furnishings	Make sure sufficient doors and windows open to allow adequate airflow.

For service or warranty support, Phone 1300 364 220 or visit www.coolbreeze.com.au

For service calls attended during the warranty period:

1. Provide the service person with proof of purchase, i.e. invoice from installing dealer
2. Where no fault has been found, service charges will be payable at the standard service rate.

COOLBREEZE PRODUCT WARRANTY TERMS AND CONDITIONS

AUSTRALIA ONLY FOR MODELS PURCHASED FROM 01 OCTOBER 2016

This AirGroup Australia (the Manufacturer) Warranty is provided in addition to and in conjunction with the statutory warranties contained in the Australian Consumer Law and provided to you as the Purchaser (the Consumer) of an AirGroup Australia product (the Product).

CoolBreeze Air Conditioning units are the product covered under warranty from the date of purchase for

Residential installations: 5 years Parts & Labour
10 years Cabinet and Structural

Commercial Installations: 2 years Parts & Labour
10 years Cabinet and Structural

TERMS AND CONDITIONS OF THE WARRANTY COVER

Should a defect or fault occur to the product due to faulty material or workmanship within the period of the warranty, AirGroup Australia will repair or replace the defective product or defective part for the original purchaser of the product. Such repairs or replacement will cover parts and labour only subject to the conditions mentioned below. The decision as to whether to repair or replace a defective product or defective part of a product will be determined at the sole discretion of AirGroup Australia.

This warranty covers only the CoolBreeze evaporative air-conditioning unit and does not cover any ducting or air distribution components, electrical or plumbing.

This Warranty does not cover a defect to the product if:

1. It is caused by accident, neglect, vandalism and/or misuse.
2. It is caused by an act of nature, such as wind, rain and/or lightning.
3. It is caused by animals, birds, insects, plants and/or any other natural cause.
4. It is caused by particles, matter or other factors in the installed environment, having an adverse effect on the product.
5. It is caused by instability of electrical or water supply, outside of the product specified ranges.
6. Unauthorised modifications and use of accessories or components not approved by the Manufacturer.
7. It has not been installed by a qualified person (who meets the Manufacturer's standards) in the manner prescribed by state or local regulations and licenses, and the manufacturer's specifications.
8. The defect is caused by factors other than normal use in accordance with the owner's manual.

This warranty does not cover :

1. Programming or set up of the product or controls, which can be done by the consumer; (as provided in the owner's manual)
2. Any problem and/or performance issues arising from faulty, incorrect and/or poor installation.
3. Inadequate sizing or not fit-for-purpose design and supply of product.
4. Products that have been re-located from the original place of installation
5. Noise and/or vibration that is considered by an authorized AirGroup Australia representative or agent(acting reasonably) to be normal operation.
6. Any costs and/or additional labour associated with gaining access to or working on a unit installed in restricted or unsafe locations including multi-storey homes.

7. Repairs outside normal Monday to Friday business hours.
8. Consequential damage and/or loss of any type whatsoever, whether such loss was incurred directly or indirectly.
9. Filter pads and consumables that are subject to operational wear and tear are specifically not included. This included scale and lime build-up caused by poor water quality
10. Changes in appearance to the product or components, unless they have a significant effect on unit function

PLACE OF SERVICE

For products that are installed further than 25km from an AirGroup Australia Designated Service Agent (DSA) a supply part only warranty applies from the Manufacturers warehouse (Perth or Melbourne). Diagnosis of the required part/s associated with repairs or replacement of parts in the product shall be borne by the Purchaser. Fitting of parts and repairs must be done by a suitably qualified and licensed person, or under the direct guidance of the manufacturer.

AirGourp Australia reserves the right to decline to comply with its obligations under this warranty, if regular maintenance service is not carried out in accordance with recommendations in the owner's manual.

Where you make a request for any form of service or repair under the Warranty, and where no defect is found by the AirGroup Australia DSA, or the defect is outside the terms and conditions of the original warranty, the purchaser will be liable for all costs incurred by AirGroup Australia service provider in complying with your request, including, but not limited to all labour, travel and administration expenses.

HOW TO MAKE A CLAIM UNDER THIS WARRANTY:

Subject to the terms and conditions of this Warranty, if you become aware of a defect in your product that is covered under this warranty, please contact the AirGroup National Service Hotline 1300 364 220.

Original, legible proof of purchase documentation (Dealer's invoice and/or receipt of payment) MUST be provided to the manufacturer, or the AirGroup Australia DSA or their designated service technician, to access any warranty services or parts. Supporting information such as the dealer and installers details and the product serial number may be required.

COSTS OF AND INCIDENTAL TO A CLAIM UNDER THIS WARRANTY

Any remedial work undertaken by AirGroup Australia or one of its approved representatives or agents will be conducted at AirGroup Australia's sole expense, subject to the terms and conditions and exclusions contained in this warranty. To the extent permitted by law, AirGroup Australia will not reimburse the purchaser for any expenses incurred in applying for a remedy under this warranty.

AUSTRALIAN CONSUMER LAW DISCLAIMER:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

TEN YEAR EXTENDED WARRANTY(MODELS PURCHASED FROM 01 OCTOBER 2016 ONLY)

In addition to the above standard five year parts and labour warranty, AirGroup Australia will extend the warranty period to a maximum of ten years for parts and labour for heritage and cascade models only and is limited to residential installations only. This extended warranty is provided subject to the following terms and conditions:

1. That the purchaser registers for the extended warranty by completing the Warranty Extension Certificate (supplied with the product in the Owner's manual booklet) and posting it to AirGroup Australia within 6 month's of purchase of the CoolBreeze air conditioner product.
2. That within the fifth year from purchase, an extension service is carried out by AirGroup Australia or their designated service agent.
3. This Warranty Extension Service will be charged to the purchaser by AirGroup Australia. The service will be carried out by An AirGroup Australia designated service agent.
4. The completion and payment for the warranty extension service will automatically extend the warranty by 2 years to a total of 7 years.
5. That within the seventh year from the purchase an extension service is carried out by AirGroup Australia or their designated service agent.
6. This Warranty Extension Service will be charged to the purchaser by AirGroup Australia. The service will be carried out by an AirGroup Australia designated service agent.
7. The completion and payment for the Warranty Extension Service will automatically extend the Warranty by 3 years to a total of 10 years
8. The Warranty Extension Service can be booked online at www.coolbreeze.com.au

This Extension Warranty is not transferable and cannot be sold, assigned or transferred by the purchaser to any other person.

Failure to register your CoolBreeze unit within 6 months of the purchase date or failure to have the Warranty Extension Service during the fifth and Seventh year will void the Extended Warranty, and the standard 5 year parts and labour warranty will apply.

This Product is Certified



RoHS



AIRGROUP AUSTRALIA

28-30 Division Street, Welshpool, Perth

Tel. 08 9350 2200

Website : www.coolbreeze.com.au